



hopspots[®]

Manual





- a. Handle
- b. iPad-holder
- c. iPad-plug
- d. Light indicator
- e. Volume-
and on/off-knob
- f. Speaker
- g. Charging shelves
for spots
- h. Wheels
- i. Cable attachment



Overview

Functions overview	2
1. Hopspots charging station	4
Functions	
Charging	
Connect the iPad	
Extra functions	
2. Before use	5
Spot master	
Switch between several iPads	
Colour pairing	
3. Directions for use of Hopspots	8
4. Cleaning	9
5. Troubleshooting	9

1. Hopspots charging station

Functions:

The charging station has several functions, it:

- connects the iPad with the spots
- contains a build-in speaker
- charges and stores the spots on the shelves

Charging:

The Hopspots-spots must be charged prior to use.

This is done by placing the spots on the charging shelves (g) and attaching the cable (i) to the charging station and a power socket.

Connect the iPad:

Before you can play with Hopspots, the charging station must be connected to the iPad.


First, place the iPad in the holder (b) and connect it to the iPad-plug (c). Turn ON bluetooth on the iPad and turn ON the charging station (e). Open the Hopspots-app

(which can be downloaded from App Store) and log into the app with your username and password.

Go to "Settings" in the app and turn "Spot master" ON. Press "Colour pairing" and follow the instructions on the screen. When the colour pairing is complete, you are ready to play (go to "Before use" for an indepth description).

Extra functions:

You can connect the iPad to a projector or a big screen if you want. You can also play without connecting the iPad to the plug on the charging station, in case you don't want to use the speaker or you want to connect the iPad to a projector/big screen. However, the charging station must be turned ON and thus wirelessly connected to the iPad.



2. Before use

Spot master:

The iPad you want to play with must have "Spot master" turned ON in the app settings and at the same time it must be turned OFF on any other iPads nearby.




Bluetooth must be turned ON on the iPad, when you want to play. Otherwise, you cannot connect.

Switch between several iPads:

If you want to switch to another iPad, the chosen iPad must be connected as the only Spot master, it must have bluetooth turned ON and the app has to be restarted.

Colour pairing:

The very first time an iPad is used with Hopspots, the spots have to be colour paired. The same is the case if you switch between several sets of spots. If you want



to play with another set of spots, you have to do a colour pairing to connect the spots with the iPad. By doing so you are sure that the chosen spots are registered with the iPad and ready to use.

Press Colour pairing under Settings and follow the in-structions on the screen (see the picture on p. 7). Step on the spot that is shown on the screen e.g., when a yellow spot is shown, step on the yellow spot. The order of the colours is preset, and you step on the 12 spots in the order that the screen shows. In that way the iPad knows which physical spots match the spots in the app.

Now, you are ready to play with Hopspots. Choose a game to play and follow the instructions on the screen.

3. Directions for use of Hopspots

Overview:

Please notice the following regarding the use of Hopspots:

- Do not immerse the Hopspots-spots, charging station and their parts into water or any other kind of liquid.
- Do not turn the charging station upside down.

- The spots can withstand a maximum load of 200 kg.
- Only tolerates indoor use on dry surfaces.

Caution! Always make sure that the non-slip rubber rings on the back of the spots work optimally before use, as the spots otherwise may slip and you may fall.

Warning! This product is not suitable for children under 3 years.

Elaborated directions for use of Hopspots:

Hopspots only tolerates indoor use on dry surfaces. Neither the spots nor the charging station tolerate outdoor use, water, moisture or any other kind of fluid. The spots can withstand a maximum load of 200 kg. Hopspots is not suitable for children under 3 years. The charging station must not face upside down when charging. The warranty is valid as long as these directions are complied with.

4. Cleaning

The spots can be cleaned with a wrung cloth with a bit of mild detergent. Make sure the spots are completely dry before placing them on the charging shelves. On the backside of the spots there are non-slip rubber rings that work best when they are free of dust and dirt. These can, like the charging station, be cleaned with a dry cloth.

5. Troubleshooting

A spot does not react or light up, what should I do?

1. Try restarting the app.
2. Charge the spot, it may have run out of power.

There is no connection between the iPad and the spots.

1. Is the charging station turned ON? If not, turn it on and check again.
2. Are more iPads set as Spot masters at the same time? Turn Spot master ON on one iPad and turn it OFF on the other iPads -

use the one you just turned ON for playing.

3. Restart the app.

4. Is the charging station out of power? Attach the power cable to the charging station and plug the other end into a power socket until it is fully charged. You can play while it charges.

Contact Aviaja Borup Lynggaard
Telephone: +45 31132618
E-mail: info@hopspots.dk

Address Nannasvej 16,
8230 Åbyhøj

www.hopspots.dk